

PULSANTI NON LUMINOSI IN METALLO - ELEMENTO FRONTALE ROTONDO

NON-ILLUMINATED PUSH BUTTON - METAL BODY - ROUND FRONT ELEMENT

	codice operatore code operator	codice attuatore code actuator	funzione function	tipo type	conf pack
	PR-010M22	ATT-804A			5
		ATT-804G		bottone rasato flush guard	5
		ATT-804V			5
	PR-020M22R	ATT-805A		bottone sporgente extended button	5
		ATT-805B			5
		ATT-805G			5
		ATT-805N			5
	PR-050M22R	PR-050M22N	instabile momentary	fungo assiale mushrooms head	5
					5
	PR-055M22R (Ø 40 mm)	PR-055M22N (Ø 40 mm)		fungo oscillante wobble mushrooms head	5
					5
					5
	PR-054M22R			leva oscillante wobble joystick	5
	PR-255M22A	ATT-804A		ripristino reset	5
		ATT-804B			5
		ATT-804G			5
		ATT-804N			5
		ATT-804R			5
		ATT-804V			5
	PR-030M22	ATT-728A		bottone rasato passo-passo protetto flush guard push-on / push-off	5
		ATT-728B			5
		ATT-728G			5
		ATT-728N			5
		ATT-728R			5
		ATT-728V			5
	PR-045M22R	PR-045M22N	stabile maintained	fungo passo-passo protetto mushroom head push-on / push-off	5
					5
	PR-065M22R (Ø 40 mm)			fungo sblocco a rotazione mushroom head twist to release	5
					5